

Cost-Effective Ink Solution For SEIKO Colorpainter 64s, 100 & oce 6060

Ink bag solution for SEIKO & OCE



Inks are supplied in pre-filled bags.



1

Open cartridge and insert an ink bag.



2

Close cartridge and recharge the chip.



3

Cartridge is ready to go on a printer!

**Plug and play solution •
No bulk system required •
Ink costs as low as the bottled ink •**

Why pay high prices for cartridges when all you need is the bagged ink?

Every time you buy a cartridge for your Seiko Colorpainter or OCE printer, you are paying for an ink in a bag, a plastic cartridge and an ink chip. Why waste money on a cartridge and a chip, if you can reuse them? Our Permanent SEIKO/OCE Chip system allows you to do that, and lowers your production costs.

SEIKO/OCE Ink Bag Solution is a small Investment Solution

Initially you need to buy the Ink Bag Solution Hardware. The solution comes with rechargeable chips, charger & software. Then you purchase the ink bags and automatically start saving, since the price of the ink bags is nearly as low as the price of the bottled ink.

Three Easy Steps

It takes only a minute to convert an ink bag into a fully functional cartridge.

1. Open the old cartridge, remove the old ink bag from it and insert the new one. Close the cartridge.
2. Attach the Chip Charger to it. Run the software on your PC and recharge the chip by a click of a button.
3. Remove the Chip Charger. The cartridge is now ready to go on your printer.

**Solvent
Cartridges
.com**

All Trade Marks Recognized